

# Download Aqualung Legend Service Manual

Legend First Stage Service Manual Procedure A Cleaning and Lubricating (All Aqualung Regulators) Cleaning brass and stainless steel parts. Pre-clean by soaking in NETALU diluted to 25%. Cleaning in an ultra-sonic bath filled with a mixture of washing-up liquid + hot water.in the servicing of Aqualung equipment during a specialised course. If you do not understand certain procedures in this manual you should contact an Aqualung service consultant before undertaking any operation. WARNINGS, ATTENTION, NOTES Certain icons have been used to facilitate the reading and understanding of this manual. They have the followingyou should contact an Aqualung service consultant before undertaking any operation. WARNINGS, ATTENTION, NOTES Certain icons have been used to facilitate the reading and understanding of this manual. They have the following ... 8 Legend First Stage Service Manual 8. Turn the regulator over so that the MP side faces you.Legend LX Second-Stage Service Manual INTRODUCTION This manual provides factory prescribed procedures for the correct service and repair of the Aqua Lung Legend LX second-stage regulator. It is not intended to be used as an instructional manual for untrained personnel. The procedures outlined within this manual are to be performed only by per-